


HOW TO FIND A IGNITION PROBLEMS Rev2 2015

info@jet-italia.it or your Local Dealer




1 BURNER ON: Burner on for 10 sencongs


2 FUEL IGNIT : Pushing GAS/BURNER Valves - Starting Fuel Pump

FUEL HEAT $\,\,$: Heating Time 150°C into 6 seconds – Segue from burner Supply to fuel ignition

3 /4 RAMP UP: Increasing to idle 35K

Ecu Show: NO KEROSENE IGNITION





Some time to increase the temperature must SET lower value of pump,

because the kerosene in excess will not burn inside!!!!!!!!

IF this Setting not solved the problem

GO to

PUMP START VOLTAGE CALIBRATION INSTRUCTION

NO LIGHT-UP

- CHECK -right connections in the ECU between Kero Valve and Gas/Burner Valve
- CHECK -connections Kero Tube and Gas/Burner Tube in the right Festo
- CHECK blow with a tube of 4mm into the Turbine Gas/Burner Nipple (usually red) if it is clogged
- **CHECK Gas/Burner Valve by the Menu 5 Test Function**
- **CHECK GLOWPLUG by the Menu 5 Test Function**
- If Ambient Temperature is less than 5°C you can Adjust 2.2 Glow Power at 7.5V
- CHECK Fuel Pump not is stuck, by push I/o platine button (between ECU & GSU)
- Problem in the Buble Trap
- **TUBE Plugged**
- **Fuel Filter Clogged**

PUMP START VOLTAGE CALIBRATION INSTRUCTION

Disconnect a KERO Main TUBE _____ put the tubes in a glass to assess quantity of kerosene filling out TEST MENU 5 — V Use arrows 1 to Set Value from 0.6 to 0.19 NOW if you PUSH \bigvee fuel pump start at the Setting Value and you can check the quantity of kerosene to stop the pump

NOW adjust the value to find a best quantity (continuously drips) NORMALY BETWEEN 0.16<0.20

IMPORTANT: THIS VALUE MUST BE INSERT TO SETUP 1.4 (PUMP START VOLTAGE) and confirm V

This procedure is very important because models have a different type of Tanks, short and longs fuel line that can be change influence this value.

IF THE PROBLEM PERSIST: CHECK NO LIGHT-UP LIST OF CONTROL

RAMP UP PROBLEM

Turbine reach 150°C into 6 Seconds? YES

1) You can check the Solenoid Valve, cables, Pipes

Menu Test N.5

Go to sub Menu TEST "KEROSENE VALVE"

And check that it's working good

2) You can made a Test Starter Motor

Go to sub Menu TEST 5 "STARTER"

And check that it's working good

IF THE PROBLEM PERSIST: CONCTACT A COMPANY PRODUCER