

Cheap Office.


EPSON STYLUS PRO cartridges refill instructions: 7400 - 7450 - 9400 - 9450 - 7800 - 7880 - 9800 - 9880

Thank you for choosing our products. Before the installation read carefully this instructions. For any clarification or technical support contact our customer service: www.cheapoffice.it

Each cartridge pack content:
1 x refillable cartridge
1 x funnel
1 x 10 ml plastic syringe
1 x plastic needle
1 x filter



1. Remove the cap in the back side of the cartridge (red arrow)




2. Insert the funnel in the hole (point 1)




3. Fill the ink tank with the ink until the ink reach the level indicated in point 4



4. Ink max level (approximately 1cm from the full fill of the cartridge).




5. Close the cap.



6. Put the needle in the syringe.



7- Put the syringe tip in the ink outlet hole (green arrow) and aspirate approximately 10ml of ink (red arrow).



Now the cartridge is ready to be put in the printer. Repeat the same operations for all the cartridges.

IMPORTANT:

The cartridges must be refilled before the ink runs out completely. If this were to happen you have to repeat all the fill operations.

FOR ANY DOUBTS CALL THE ASSISTANCE +39 0522/260545

IMPORTANT!

Do not open the cartridge cap when it is in the turned on machine. Before remove the cartridge cap turn off the printer or remove the cartridge from the printer.

**DISTRIBUTED BY
CHEAP OFFICE
tel. 0522260545
Fax. 0522524725
www.cheapoffice.it**